


Using **AFNI** Interactively — More details than you want to know

- Start AFNI from the command line
 - ★ **afni** reads datasets from the current directory
 - ✧ If no datasets in current directory, tries to read sub-directories 1 level deeper
 - ★ **afni dir1 dir2 ...** reads datasets from directories listed
 - ★ **afni -R** reads datasets from the current directory and from all directories below it
- AFNI reads the file named **.afnirc** from your home directory, if it is present
 - ★ This file is used to change many of the defaults (cf. File **README.environment**)



- Miscellaneous features of the AFNI controller window:

- ★ xyz -coordinate display in upper left corner shows current focus location
 - ✧ By default, the coordinates are in RAI order (from the DICOM standard):
 - ↳ x = Right (negative) to Left (positive)
 - ↳ y = Anterior (negative) to Posterior (positive)
 - ↳ z = Interior (negative) to Superior (positive)
 - ✧ This display order can be changed to the neuroscience imaging order LPI:
 - ↳ x = Left (negative) to Right (positive)
 - ↳ y = Posterior (negative) to Anterior (positive)
 - ↳ z = Interior (negative) to Superior (positive)
 - ↳ Right-click in coordinate display to change the coordinate order
- ★ The [**Bhelp**] button: when pressed, the cursor changes to a hand shape; use it to click on any AFNI button and you will get a small help popup
 - ✧ AFNI also has 'hints' (AKA 'tooltips')
- ★ Press the [**New**] button to open a new AFNI controller
- ★ Used to look at more than one dataset at a time
 - ✧ [**Define Datamode**] ⇒ [**Lock**] can be used to lock controllers together by coordinates
 - ↳ All viewing windows within a controller are *always* locked together
 - ✧ Press the [**Views**] button to close/open the control panel at right
 - ↳ Button with inverted colors means that control panel or window is open


- ★ Press the [**done**] button **twice** within 5 seconds to exit AFNI
 - ✧ The first button press changes '**done**' to '**DONE**'
 - ↳ Fail to press second time in 5 seconds: it changes back to '**done**'
 - ✧ Whatever you do, *don't* press a mouse button in the blank square to the right of [**done**]
 - ↳ We won't be responsible for the consequences
- ★ The [**Switch**] buttons let you control which datasets are being viewed
 - ✧ [**Switch Session**] controls which directory datasets are viewable
 - ↳ All datasets in same directory are assumed to be aligned in space
 - ↳ Any dataset can be the underlay; any dataset can be the overlay
 - ✧ [**Underlay**] control the background (grayscale) dataset — anatomical dataset usually goes here
 - ↳ Current underlay dataset determines the resolution of and 3D region covered by image viewers
 - ✧ [**Overlay**] controls the overlay (color) dataset — functional (statistical) dataset usually goes here
 - ↳ Functional datasets will be interpolated — if needed — to the underlay resolution, and flipped — if needed — to that orientation
 - Interpolation method controlled in [**Define Datamode**] panel
 - ✧ Current datasets are named in AFNI controller titlebar: look at it!

- Dataset “chooser” window

- ★ List of datasets available in the current directory
- ★ Left column has prefix names of datasets
- ★ Right column has a little information about each dataset
 - ✧ How dataset was classified in `to3d`
 - ✧ Number of sub-bricks

- To choose a dataset

- ★ Click on label, or scroll with mouse scroll-wheel, or use keyboard arrows
- ★ Press [**Apply**] button to select the highlighted dataset, and also keep the chooser window open
- ★ Press [**Set**] button to select the highlighted dataset, and also close the chooser window
- ★ For the advanced and highly intellectual user:
 - ✧ Set environment variable `AFNI_DATASET_BROWSE` to `YES` to have AFNI switch to that dataset immediately upon selection (don't need to use [**Apply**] or [**Set**])
 - ✧ Environment variables can be set in your `.afnirc` file, or by using the [**Edit Environment**] control panel (cf. [**Define Datamode**] ⇒ [**Misc**])



- ★ The [[RescanTh](#)] button checks the session (data directory) that you are currently working in for new datasets
 - ✧ Use this feature when when you create a new dataset using a command line program (like [3dcalc](#)) outside of the AFNI interface, and then want to see it
 - ✧ [[RescanTh](#)] same as [[Define Datamode](#)] ⇒ [[Rescan This](#)]
 - ↳ This duplicate button added 02 Feb 2007 in response to AFNI workshop users from Princeton University
 - ↳ If you set [AFNI_RESCAN_AT_SWITCH](#) to [YES](#), then [[RescanTh](#)] is done whenever you press [[Underlay](#)] or [[Underlay](#)]
- ★ The [[NIML+PO](#)] button tells AFNI to start listening for TCP/IP (network socket) connections from external programs
 - ✧ [SUMA](#) = SUrface MApper
 - ↳ Can exchange data with AFNI for two-way interactive display of data on cortical surface models in SUMA and in 3D volumes in AFNI
 - ✧ [plugout_drive](#)
 - ↳ Program can send commands to AFNI that act like button presses in the AFNI controller windows
 - ↳ Example: You can write a [script](#) (a list of commands) to make AFNI open image windows, and save an image window to a JPEG file
 - ✧ You can write your own program to connect to AFNI and send data and send commands (if you are a programmer, that is)
 - ✧ [[NIML+PO](#)] duplicates buttons on [[Define Datamode](#)] ⇒ [[Misc](#)] menu — also added on 02 Feb 2007

The Define Datamode Control Panel

The image shows a software control panel with several sections and buttons. Red arrows point from text annotations to specific elements in the panel:

- How to get data from 3D array to 2D image slices for display:** Points to the 'View ULayer Data Brick', 'Warp ULayer on Demand', 'View OLayer Data Brick', and 'Warp OLayer on Demand' buttons.
- 3D-to-2D interpolation methods:** Points to the 'NN' dropdown menus for 'OLay resam mode' and 'Stat resam mode'.
- Write copies of datasets to disk:** Points to the 'Write' button.
- Re-read sessions (directories) to look for new dataset files:** Points to the 'Rescan' button.
- Menu of AFNI plugins:** Points to the 'Plugins' button.
- Menu of miscellaneous commands:** Points to the 'Misc' button.
- Lock AFNI controller viewpoints together (in space and time):** Points to the 'Lock' button.


The control panel itself contains the following elements:

- Buttons: View ULayer Data Brick, Warp ULayer on Demand, View OLayer Data Brick, Warp OLayer on Demand, Write, Rescan, Read, Lock, Misc, Plugins.
- Dropdowns: ULayer resam mode (LI), Rescan (mm) (1), OLayer resam mode (NN), Stat resam mode (NN).
- Buttons: ULayer, OLayer, Many, This, All, Sess, 1D, Web.

Lock Menu


Misc Menu

Which AFNI controllers are locked together in xyz coordinates



Lock Time Index also?

N.B.: There is only one lock



Popup hints?
Show dataset info
Settings for AFNI GUI
Save AFNI GUI setup
Show some informational messages
Clear datasets from RAM
Debugging

N.B.: Most menus can be "torn off"

- Touring the Image Viewer





Image viewer window

Disp and Mont control panels


- ★ Crosshairs in image window show current focus location (=xyz in AFNI controller)
 - ✧ Also show the cut planes for the other image viewers
 - ✧ When using image montage, other viewers show multiple crosshairs
 - ✧ Can control crosshair color and gap size from main AFNI controller
- ★ Slider below image lets you move between slices
 - ✧ Left-click and drag 'thumb' to move past many slices
 - ✧ Left-click ahead or behind thumb to move 1 image at a time
 - Hold button click down to scroll continuously through slices
 - ✧ Middle-click in 'trough' to jump quickly to a given location
 - ✧ Mouse scroll-wheel action *when cursor is over image* also changes slices
- ★ Vertical intensity bar to right of image shows mapping from numbers stored in image to colors shown on screen
 - ✧ Bottom of intensity bar corresponds to smallest numbers displayed
 - ✧ Top corresponds to largest numbers displayed (popup hint shows numerical range)
 - ✧ Smallest-to-largest display range is selected from [**Disp**] control panel
 - or from hidden right-click popup menu on intensity bar
 - ✧ All image viewers from all AFNI controllers use the same intensity bar
 - so when you change intensity scale in one viewer, all others viewers change
 - unless AFNI is started with the **-uniq** command line option, in which case each AFNI controller's viewers have independent intensity bars
 - but all image viewers from same controller always share same intensity bar
 - ✧ Mouse scroll-wheel action *when cursor is over intensity bar* changes contrast

★ Buttons at right of image viewer window



- ✧ [Colr] changes grayscale to color spectrum, and back (fun & useless)
- ✧ [Swap] swaps top of intensity bar with bottom
- ✧ [Norm] returns the intensity bar to normal (after you mess it up)
- ✧ [c] controls contrast
- ✧ [b] controls brightness
 - ↳ Useful combination [c] ▲ 2-3 times, [b] ▼ 2-3 times
- ✧ [R] rotates the intensity bar (also fun & useless)
- ✧ [g] changes the gamma factor (nonlinearity) for the intensity bar
- ✧ [i] changes the size of the image in the window
- ✧ [9] changes the opacity of the color overlay
 - ↳ This control only present for X11 TrueColor displays
- ✧ [z] zooms out and in
- ✧ [pan] lets you pan around when zoomed in
- ✧ [crop] lets you crop the image viewing area

★ At bottom right, the arrowpad controls the crosshairs



- ✧ Arrows move 1 pixel in that direction for that window
 - ↳ Sagittal ◀ is same as Axial ▲
- ✧ Central button closes and opens crosshair gap (for fine control of where the crosshairs are)
- ✧ Items on AFNI controller (below xyz display) also alter crosshairs
 - ↳ Can change color, gap size, ...

★ Buttons along bottom of image viewer window provide various services

✧ **[Disp]** controls the way images are displayed and saved

➔ Pops up its own control window: most controls change image immediately

➔ Orientation controls at top allow you to flip image around

➔ **[No Overlay]** lets you turn color overlays off (crosshairs; function)

➔ **[Min-to-Max]** ⇒ intensity bar is data min-to-max

➔ **[2%-to-98%]** ⇒ intensity bar is smallest 2% of data to largest 98%

• Avoids having a few very bright voxels dominate intensity scaling

➔ **[Free Aspect]** lets you distort image shape freely

• Otherwise, AFNI tries to keep image shape “true” as you stretch/shrink window

➔ **[Save panel]** controls how images are saved to disk:

• All buttons off ⇒ saved image file contains slice raw data (not what you want)

• **[Nsize Save]** ⇒ same, but images are 2^N in size

• **[PNM Save]** ⇒ images are saved in PPM/PGM format (color/gray)

• **[Save to .xxx(s)]** ⇒ saves image(s) to specified format

• **[Save One]** ⇒ for saving montage

➔ **[Tran 0D]** lets you transform voxel values before display

• **[Log10]** and **[SSqrt]** useful for images with extreme values

➔ **[Tran 2D]** provides some 2D image filters (underlay only)

• **[Median 9]** smoothing can be useful for printing images

➔ **[Rowgraphs]** lets you graph the voxel values from image rows

• If you want columns, flip the image with **[CCW 90]**

➔ **[Surfgraph]** lets you graph the voxel values in a surface graph



- Three extra imaging processing filters are provided at the bottom
 - **[Sharpen]** is sometimes useful for deblurring images
- **[Reset]** sets controls back to what they were when you opened **[Disp]**
- **[Done]** closes this control window

★ **[Save]** lets you save images from viewer to disk files

◇ Warning: Images are saved as sent to the viewer, not as displayed

- Means that aspect ratio of saved image may be wrong (non-square pixels)
- Can fix this with **[Define Datamode]** ⇒ **[Warp Anat on Demand]**
 - Or by setting `AFNI_IMAGE_SAVESQUARE` to `YES`

◇ **[Save:bkg]** means it will save the background image data itself, whatever the format it may be in (bytes, shorts, floats, complex numbers, RGB byte triples)

◇ **[Save:pnm]** means it will save the displayed image in PNM format


- PPM for color, PGM for gray-only images
- You might have to convert this to some other format
- See AFNI FAQ #57 for instructions on image format conversion

◇ **[Sav1:xxx]** means it will save the entire Montage in format “xxx”

- This is the only way to save a Montage layout (within AFNI)
- **[Save]** options will only save single slice images (one or more)


◇ **[Save.xxx]** means it will save image in the “xxx” format

- You can also set this using the hidden right-click popup on the **[Save]** Button itself (so you don't need to open & close **[Disp]** just for this)
- Format list depend on presence of image conversion programs on your system



- ◇ After you press [**Save**], then it asks for a filename prefix
 - ◇ Except for [**Sav1.xxx**], it then asks for 'from' and 'to' slice indexes
 - ↳ You can save many images this way
 - ↳ Filenames are like are like **prefix.0037.ppm**, for slice #37, ppm format
 - ↳ [**Sav1.xxx**] immediately saves its one file after prefix is entered
-

- ★ [**Mont**] lets you display a rectangular layout of images (i.e., montage)
 - ◇ Pops up its own little control window
 - ↳ Controls at top do nothing until an action is selected on bottom row
 - ◇ [**Across**] and [**Down**] determine number of sub-images shown
 - ◇ [**Spacing**] determines how far apart the selected slices are
 - ↳ Every n^{th} slice, for $n = 1, 2, \dots$
 - ↳ Multiple crosshairs in other image viewers will show montage slices
 - ◇ [**Border**] lets you put some blank pixels between sub-images
 - ↳ [**Color**] lets you choose the color of the border pixels
 - ◇ At bottom row, the action buttons cause something to happen:
 - ↳ [**Quit**] closes the Montage control window
 - ↳ [**1x1**] changes Across and Down back to 1
 - ↳ [**Draw**] actually causes the montage to be drawn
 - ↳ [**Set**] \leftrightarrow [**Draw**] then [**Quit**]



★ **[Rec]** lets you record images for later **Save**-ing



✧ So you can build a sequence of images using any set of AFNI controls

➤ Change color maps, functional thresholds, datasets, ...

✧ Then save them to disk for animation, etc.

➤ If Unix programs **whirlgif** and/or **gifsicle** are installed on your system, AFNI can write GIF animations directly (e.g., for fun Web pages)

➤ If program **mpeg_encode** is installed, AFNI can write MPEG-1 animations

➤ Source code for these free programs is included with AFNI source code

✧ **[Rec]** button pops down a menu that sets the record mode

➤ **[Off]** ⇒ recording is off

➤ **[Next One]** ⇒ next image displayed is recorded, then back to **[Off]**

➤ **[Stay On]** ⇒ record each image when displayed

➤ Controls below the line determine where in the recording sequence the saved images will be stored as they are created

✧ Recorded images go into a special new image viewer


➤ Slider moves between recorded images

➤ **[Kill]** deletes 1 image from recorded sequence

➤ **[Save]** will save record images

• Right-click on **[Save]** for format menu

➤ **[Done]** to close the recorded image viewer




★ Hidden image popup menu (using Button 3 or right-click)



- ✧ [[Jumpback](#)] lets you jump the focus position back to its last place
 - For when you click in the wrong place and get lost
 - ✧ [[Jump to \(xyz\)](#)] lets you enter *xyz*-coordinates (in mm), and then the focus position will jump there
 - External program 3dclust can generate *xyz* coordinates of interest
 - Once you have **+t1rc** dataset, can jump to regions from Talairach atlas
 - ✧ [[Jump to \(ijk\)](#)] lets you jump to a particular voxel index location
 - ✧ [[Image display](#)] lets you turn control widgets on and off
 - Can unclutter screen a little; useful if you want to make a screenshot
 - ✧ Other items bring up controls that are discussed in other presentations
-

★ Hidden intensity bar popup menu



- ✧ [[Choose Display Range](#)] lets you pick the exact range of numbers that are mapped to intensity bar colors
 - Normally, each slice image is mapped to colors separately when it is displayed
 - Using **Min-to-Max** or **2%-to-98%** from [[Disp](#)]
 - If you want each image to be mapped the same way, then must give bottom-to-top values via this menu item (separate them with spaces)
 - If you set third (optional) input '**ztop**' to 1, values above '**top**' are set to 0
 - To restore normal auto-mapping, set '**bot**' and '**top**' both to 0

- ✧ [**Choose Zero Color**] lets you choose the color that is displayed for voxel values that are exactly 0
 - ↳ Can be useful for filling in regions that were set to 0 by some program
 - ↳ For example, values below 'bot' from Choose Display Range (and above 'top' if 'ztop' was set to 1)
 - ↳ Choose the 'none' color to return to normal display
- ✧ [**Choose Flatten Range**] is used to control the Flatten filter from the [**Disp**] control window
 - ↳ This is almost useless — don't bother to try it
- ✧ [**Choose Sharpen Factor**] is used to control the Sharpen filter from the [**Disp**] control window
 - ↳ Larger values mean more sharpening (and more image graininess)
- ✧ [**Plot Overlay Plots**] turns overlay graphs on and off
 - ↳ Among other things, controls overlay of cortical surface geometry sent to AFNI from the SUMA program
- ✧ [**Label**] and [**Size**] control display of slice coordinate overlay plot
- ✧ [**Tick Div**] controls tick marks plotted around the outside of image


- Keyboard shortcuts *while cursor is in the image window*
 - ★ **q** = quit = close the viewer window
 - ★ **v** or **V** = video = move through slices automatically
 - ★ **r** or **R** = rebound video
 - ★ **z** or **Z** = zoom out or in
 - ★ **p** = turn panning on or off (when zoomed in)
 - ★ **c** = turn cropping rectangle on or off
 - ★ **i** or **I** = change image fraction down or up
 - ★ **m** = switch between Min-to-Max and 2%-to-98% scaling
 - ★ **a** = fix image aspect ratio (if it gets deranged by windowing system)
 - ★ **D** = open **Disp** window
 - ★ **M** = open **Mont** window (N.B.: **Disp** and **Mont** are mutually exclusive!)
 - ★ **S** = open **Save** window
 - ★ **o** = turn color overlay display on and off (like [**See Overlay**] in AFNI GUI)
 - ★ **u** = switch the overlay dataset to be the underlay dataset temporarily
 - ★ keyboard arrow keys = move cursor one voxel (like arrowpad)
 - ★ **PageUp** and **PageDown** = change slice

 - ★ **Delete** = ROI drawing plugin 'Undo'
 - ★ **F2** = Change to 'pencil' mode when using the ROI drawing plugin

- Mousing shortcuts in the image viewer
 - ★ Click down Button 1 (left button) in the image window and ***hold it down***, then drag around while holding
 - ✧ Changes contrast and brightness
 - ✧ With a little practice, becomes an easy way to adjust images to your liking
 - ✧ Click-and-release in the same spot just causes crosshairs to move
 - ✧ You must move cursor a small distance while doing click-and-hold before the contrast/brightness change starts
 - ★ As mentioned earlier, scroll-wheel in the image window moves through slices
 - ★ Keyboard **ALT** (**option** on Macintosh) while using scroll-wheel in the image window will change the functional overlay threshold slider in the main AFNI GUI window
 - ✧ This action affects all image viewers in the current AFNI controller
 - ✧ Shift+scroll and Control+scroll are special on the Macintosh, and so are not used in AFNI

- As mentioned earlier, scroll-wheel in the intensity bar changes contrast
 - ★ **ALT** or **option** plus scroll-wheel in intensity bar changes brightness

- Touring the Graph Viewer




Graph Viewer with data (black) and reference waveforms (red)


- ★ Graph viewer takes voxel values from same dataset as image viewer
 - ✧ If dataset has only 1 sub-brick, graph viewer only shows numbers
 - Not very useful unless you are an MRI physics type, perhaps
 - ✧ To look at images from one dataset locked to graphs from another dataset, must use **2** AFNI controllers and [[Define Datamode](#)] ⇒ [[Lock](#)] on AFNI control panel
- ★ If graph and image viewer in same slice orientation are both open, crosshairs in image window change to show a box containing dataset voxels being graphed
- ★ Central sub-graph (current focus location) is outlined in yellow
 - ✧ Current time index is marked with small red diamond on data graph
 - ✧ Left-clicking in a non-central sub-graph moves that location to focus
 - ✧ Left-clicking in central sub-graph moves time index to nearest point
 - Can also use [[Index](#)] control in AFNI controller to change time
 - ✧ Right-clicking in any sub-graph pops up some statistics of its data
 - ✧ Left-clicking in icon (lower left corner) causes icon and menu buttons to disappear
 - Useful if you want to do a screenshot to save AFNI window(s)
 - Left-clicking in same place will bring icon and buttons back

- ★ **[Opt]** menu buttons let you control how graphs appear
 - ✧ Many items have **keyboard** shortcuts
 - ➔ Make sure you are typing into the correct window!
 - ✧ **[Scale]** changes scale of graphs
 - ➔ Mapping from voxel values to screen pixels
 - ➔ **Down** **[-]** shrinks graphs vertically; **Up** **[+]** expands them
 - ➔ **Auto** **[a]** makes AFNI pick a nice scale factor
 - ➔ **[Choose]** lets you pick exact scale factor
 - Positive values (pix/datum) or negative (datum/pix)
 - **pix/datum** = number of *y* screen pixels for each change of 1 in data
 - or **datum/pix** = size of change in data to get 1 *y* screen pixel
 - ➔ Current scale factor is shown below graphs
 - ➔ Scale factor does *not* change when you resize graph, change matrix, etc.
 - You usually have to auto-scale **[a]** afterwards
 - ✧ **[Matrix]** changes number of sub-graphs
 - ➔ **Down** **[m]** and **Up** **[M]** decrease and increase number
 - ➔ **[Choose]** lets you pick number exactly
 - Alternative: keyboard **[N]**, type number, then **[Enter]** key
 - Range of allowable matrix size is 1..21



- ✧ **[Grid]** lets you change spacing of vertical grid lines
 - Useful for showing regular timing interval (e.g., block timings)
 - **Down [g]** and **Up [G]** decrease and increase spacing
 - **[Choose]** lets you pick number exactly
 - Current grid spacing is shown below graphs
 - **[Index Pin]** lets you pick the horizontal length of the sub-graph
 - Default **Top** is number of sub-bricks in dataset
 - Make it longer \Rightarrow graphs end before window
 - Make it shorter \Rightarrow graphs are truncated
 - Useful when switching between datasets of different lengths
 - Set **Bot** and **Top** to 0 to get back to default operation
 - Current number of time points is shown below graphs
 - **HorZ [h]** will put in a dashed line at the $y = 0$ level in sub-graphs
 - Only useful if data range spans negative and positive values!
- ✧ **[Slice]** lets you change slices
 - **Down [z]** and **Up [Z]** move one slice
 - Can also choose slice directly from menu
 - Current voxel indexes are shown below graphs
 - Corresponds to **[Voxel Coords?]** Display in AFNI controller (from **Define Datamode** \Rightarrow **Misc** menu)





- ✧ **[Colors, Etc.]** lets you alter the colors/lines used for drawing
 - ↳ Lines used for sub-graph frame boxes, grid lines, data graphs, FIM orts/ideals, and double plots can have color changes and be made thicker
 - Grid color is also used to highlight central sub-graph
 - ↳ Can choose to graph curves as lines, points, or both together
 - ↳ Can change color of background and text
 - ↳ Can change gap between sub-graph boxes
- ✧ **Baseline [b]** changes how the sub-graphs are plotted
 - ↳ All sub-graphs have same scale factor, to convert values into vertical pixels
 - ↳ Baseline is value that gets plotted to bottom of sub-graph
 - ↳ Individual: all sub-graphs have different baselines
 - Baseline = smallest value in each displayed time series
 - This can be confusing; same vertical location *doesn't* mean same value
 - Shown below graphs as Base: separate
 - ↳ Common: all sub-graphs shown at any one time get same baseline
 - Baseline = smallest value in all displayed time series
 - Shown below graphs as Base: common
 - Usually need to rescale [a] after changing baseline
 - ↳ Global: all sub-graphs get same baseline even when spatial position changes
 - Set from [**Baseline**] ⇒ [**Set Global**] menu item
 - Default global level is smallest value in entire dataset

- ➔ Range of central sub-graph is shown at left of graph region
 - Central sub-graph bottom (baseline) value is shown at lower left
 - Upper left shows value at top of central sub-graph box
 - Number in [brackets] shows data range of one sub-graph box's height
 - If baselines are separate, bot/top values only apply to *central* sub-graph
- ✧ **Show text?** [t] allows you to see text display of values instead of graphs
- ✧ **Save PNM** [s] lets you save a snapshot of window to a PNM image file
 - ➔ **But:** if filename ends in “.jpg”, will actually write a JPEG image file!
- ✧ **Write Center** [w] lets you write data from central sub-graph to a file
 - ➔ File is in ASCII format ⇒ can be imported into other programs
 - ➔ Filename is of form xxx_yyy_zzz.suffix.1D (using voxel indexes)
 - ➔ Suffix is chosen using [Set 'w' suffix] button
- ✧ [Tran 0D] and [Tran 1D] let you transform the data before it is graphed
 - ➔ [Log10] and [SSqrt] useful for images with extreme values
 - ➔ [Median3] and [OSfilt3] are for are for smoothing time series
 - ➔ Other choices are functions controlled by/from plugins
 - ➔ [Double Plot] lets you plot output of [Tran 1D] and original data together
 - Color of transformed data from [Dplot] on the [Colors, Etc.] menu
 - [Dataset#2] transformation lets you plot two datasets together
 - [Dataset#N] lets you plot multiple datasets as overlay

- ✧ [**X-axis**] menu lets you choose how graph x -axis is chosen
 - ↳ Default: x is linear in time
 - ↳ Can instead choose x from a .1D format file from disk
 - ↳ Useful only in very limited circumstances!
- ✧ **Done** [**q**] closes the graph viewer window
- ★ **Keystrokes** in graphs that have no menu items are:
 - ✧ [**<**] or left-arrow key moves time index down by 1
 - ✧ [**>**] or right-arrow key moves time index up by 1
 - ✧ [**1**] moves time index to beginning (time index = 0)
 - ✧ [**l**] moves time index to end
 - ✧ [**L**] turns off/on the AFNI logo in the corner
 - ✧ [**v V r R**] are video mode operations, like in the image viewer
 - ↳ Moving through time index, rather than slice index
 - ↳ An easy way to animate an EPI time series, to look for subject motion
- ★ [**FIM**] menu controls interactive functional image calculations
 - ✧ Not documented here
 - ✧ See 'Educational materials' pages at AFNI Web site (maybe)

• Brief Tour of the Functional Color Overlay Controls

★ Open with [[Define Overlay](#)] button on AFNI controller

The image shows a screenshot of the AFNI Functional Color Overlay Controls dialog box. The dialog is titled "F-t Inten Options" and contains several sections. On the left, there is a vertical color map slider labeled "Color map" with a "Threshold slider" below it. The slider shows a range from -1.00 to 1.00, with a current threshold of .5000. Below the slider, there are checkboxes for "Positive-only or both signs of function?" and "Number of panes in color map". The "Options" section on the right includes a "Hidden popup menu here" and a "Choose which dataset makes the underlay image" dropdown. Below this are three sub-brick selection boxes: "Ulay #0 #0", "OLay #20 Tool[0] Coef", and "Thr #22 Tool F-stat". A table below these boxes shows data ranges for Ulay, OLay, and Thr. There is also a "Rota" dropdown menu and a "See TT Atlas Regions" checkbox. At the bottom, there are fields for "Shows voxel values at focus" and "Lets you choose range for color scaling".

Color map

Hidden popup menu here

Choose which dataset makes the underlay image

Choose which sub-brick from Underlay dataset to display (usually Anat – has only 1 sub-brick)

Choose which sub-brick of functional dataset makes the color

Choose which sub-brick of functional dataset is the Threshold

Shows ranges of data in Underlay and Overlay dataset sub-bricks

Shows automatic range for color scaling

Rotates color map

Lets you choose range for color scaling

Shows voxel values at focus

Number of panes in color map

Shows voxel values at focus

Positive-only or both signs of function?

Choose range of threshold slider, in powers of 10

Nominal *p*-value of current threshold

Threshold slider

AFNI Plugins

- Plugins are modules (programs) that attach themselves to AFNI when AFNI starts and add some interactive capabilities to the GUI program
- There is a (somewhat old) manual for writing plugins
- Useful plugins:
 - ★ **3D Registration:**
Provides a GUI control for time series registration (same as 3dvolreg)
 - ★ **Dataset Copy:**
Copy a dataset (useful as a start for ROI drawing)
 - ★ **Dataset NOTES:**
Add arbitrary text notes to a dataset header
 - ★ **Draw Dataset, Gyrus Finder:**
Draw regions-of-interest (ROIs) on 2D slices
 - ★ **Histogram:**
Graph the histogram of a sub-brick, or some parts of it
 - ★ **Deconvolution, Nlfit & Nlerr:**
Do linear and nonlinear regression interactively on the dataset time series being displayed in a graph viewer

Plugins Menu

-- Cancel --	Dataset#N	NLfit & NLerr
2D Registration	Deconvolution	Nudge Dataset
3D Cluster	Draw Dataset	Permutation Test
3D Correlation	Dset Zeropad	Power Spectrum
3D Dump98	Edit Tagset	Render [new]
3D Edit	Expr 0D	Render Dataset
3D Registration	Fourier Stuff	Reorder
3D+t Extract	Gyrus Finder	RETROICOR
3D+t Statistic	Hemi-subtract	ROI Average
4D Dump	Hilbert Delay98	ROI Plot
BRIC Compressor	Histogram	ScatterPlot
Coord Order	Histogram: BFit	SingleTrial Avg
Dataset Copy	Histogram: CC	Threshold
Dataset Dup	L1_Fit & Dtr	TS Generate
Dataset NOTES	LSqFit & Dtr	Vol2Surf
Dataset Rename	maskcalc	Wavelets
Dataset#2	Maxima	

Colors of plugin buttons can be set in your `.afnirc` file

★ Render Dataset: Volume rendering with functional overlays

Pick new underlay dataset Name of underlay dataset Sub-brick to display Open color overlay controls

Range of values in underlay

Change mapping from values in dataset to brightness in image

Mapping from values to opacity

Cutout parts of 3D volume

Compute many images in a row

Show 2D crosshairs

Control viewing angles

Detailed instructions Force a new image to be rendered Reload values from the dataset Close all rendering windows

Range of values to render

Histogram of values in underlay dataset

Maximum voxel opacity


Menu to control scripting (control rendering from a file)

Render new image immediately when a control is changed

Accumulate a history of rendered images (can later save to an animation)

The screenshot shows the AFNI C Renderer window with the following elements:

- Path: data/subjects/DD_noskull+orig [anat]z
- Choose Underlay Dataset: Brick #0 MINC[0]
- Min=0 Max=444
- Bot: 30, Top: 140
- Brightness and Opacity graphs with 'Line' and 'Crv' options.
- Sqrt Histogram showing a distribution of values.
- Cutouts: OR
- Opacity Factor: 1
- Scripts menu
- Automate: Frames 5, Compute button
- Interp: Neighbor, See Xhairs, DynaDraw, Accumulate
- Viewing angles: Roll 70, Pitch 120, Yaw 0
- Buttons: Help, Draw, Reload, done



Being close to your FMRI data doesn't get any better than this!

Using AFNI in Batch Mode

- Batch mode programs are run by typing commands directly to the computer, or by putting these commands into text files (*scripts*) and later executing them
- Advantages of batch mode (over graphical user interface)
 - ★ Can process new datasets exactly the same way as previous ones
 - ★ Can link together a series of programs to produce custom results
 - ★ Programs that take a long time to operate are easier to 'fire and forget' from a script than if they had a GUI
 - ★ It's easier to write a batch mode program
- Disadvantages of batch mode
 - ★ Requires typing, rather than pointing-and-clicking
 - ★ Requires learning/remembering how a program works all at once, rather than (re)discovering it through a kinder gentler interface
 - ★ Many younger (born after 1970) researchers have virtually no experience with a command line interface, or anything like it
- Many significant AFNI capabilities are only available in batch mode programs
 - ★ This is especially true of functions that combine data from multiple datasets to produce new datasets

- The **3d*** series of programs (generally) take as input one or more AFNI datasets, and produce as output one (or more) new AFNI datasets
- Time series activation analysis programs:
 - ★ **3dfim**, **3dfim+**, **3ddelay**
Variations on 'classical' correlation analysis of each voxel's time series with a single reference (ideal) waveform
 - ★ **3dDeconvolve**:
Multiple linear regression and/or linear deconvolution to fit each voxel's time series to a multi-dimensional signal model (similar models are found in SPM)
 - ★ **3dNLfim**:
Nonlinear regression to fit each voxel's time series to an arbitrary functional model provided by the user
- Time series utility programs:
 - ★ **3dFourier**:
Fourier domain filtering voxels time series
 - ★ **3dTcorrelate**:
Compute correlation coefficient of 2 datasets, voxel-by-voxel
 - ★ **3dTsmooth**:
Smooth voxel time series

★ 3dTqual, 3dToutcount:

Examine voxel time series for statistical 'outliers'

★ 3dTcat:

Shift voxel time series to a common temporal region

★ 3dTstat:

Basic statistics on voxel time series

★ 3dvolreg:

Volume registration to suppress motion artifacts, and to align same-subject data from different scanning sessions

• Multi-dataset statistical operations:

★ 3dttest:

Voxel-by-voxel t-tests

★ 3dANOVA, 3dANOVA2, 3dANOVA3:

1-, 2-, and 3-way voxel-by-voxel ANOVAs, including random effects and nested models

★ 3dFriedman:

Voxel-by-voxel nonparametric statistical tests analogous to ANOVAs

★ 3dRegAna:

General linear regression models and tests derived therefrom

- Miscellaneous operations on datasets:

- ★ 3dAnatNudge:

- Try to align high-resolution anatomical volume with low-resolution EPI volume

- ★ 3dClipLevel:

- Find the voxel value to threshold EPI volume so as to remove most of the non-brain tissue

- ★ 3dIntracranial:

- Strip the scalp and other non-brain tissue from a high-resolution T1-weighted anatomical volume

- ★ 3dMean:

- Compute the mean of a collection of datasets, voxel-by-voxel

- ★ 3dmaskdump, 3dmaskave, 3dROIstats:

- Extract values from datasets and write to ASCII files

- ★ 3dUndump:

- Take values from ASCII files and write into a dataset

- ★ 3dmerge:

- Lots of options to edit datasets and combine them in multifarious and nefarious ways

- ★ 3dZeropad, 3dZcutup, 3dZcat, 3dZregrid:

- Utilities to add/subtract/resample datasets in the slice (z) direction

★ **3daxialize:**

Re-write a dataset in a new slice direction

★ **3dcalc:**

General purpose voxel-by-voxel dataset calculator

★ **3dresample, 3dfractionize:**

Resample a binary mask dataset from one resolution to another

★ **3drotate:**

Rotate a dataset to a new orientation in space

★ **3dpc:**

Extract principal components from a collection of datasets

★ **3dWinsor:**

Spatially filter a T1-weighted anatomical dataset to reduce noise and make the gray-white matter boundary a little more distinct

★ **3dclust:**

Find clusters of activated voxels and print out statistics about them

★ **3dExtrema:**

Find local extrema (maxima or minima) in a dataset --- intended for functional activation maps